

Exhaust Servo Eliminator Supplementary Manual

BMW R1200 ABS TC Euro 3 spec 2009-2014 (ESE-BM1)

Secure the bike on a stand.



Locate the exhaust servo motor.

(At the left footpeg)



Remove the exhaust servo motor and
unplug the exhaust servo motor
connector.

(Black, 4-pole connector)



Exhaust Servo Eliminator Supplementary Manual



BMW R1200 ABS TC Euro 3 spec 2009-2014 (ESE-BM1)

Plug the ESE connectors to the exhaust servo motor connectors.

Secure the unit properly.

